Site Surveying and Antenna Mounting

Abdus Salam ICTP, February 2006 School on Wireless Networking for Development

Ermanno Pietrosemoli Latin American Networking School (Fundación EsLaRed) – ULA Mérida Venezuela www.eslared.org.ve

2/16/2006

Session Overview

Site survey Antenna mounting requirements Wall side mounts **Roof mounts Guyed towers** Self supporting tower Typical installation

LUGARES DE INTERES

 OWCHED PALKONTOLDUCC, non in stabilities pr Factor memoritation as to require

 Ownrockhow of LA VILLA, and in require as North Report GPS

Compass

OTFORT AND A SATUARIO DE FAQUA Y FLO-RA SAN PEDRO DE ISUADUE, por la ruis Ausando ne fui ignegen heria la satuata Chana

Officients at Entrances per la cabate Chrystel, andre de entrances y aroles ha on a LAGUNA DE HOLACUE, sans de la harmentale argin is Monargin Municipal

OPUINAS DE GACHARTIVA VIEJO, enripeo mentamante de localamines, her poeter fanceaux OCASCADA DE LA PERIQUERA, y senders fai des local mentoles, eques altos del rio La Ca bana.

OFL FOSIL, Cronstearre de 120 milieres :

OFUINAS DE LA INLESIA DE MONQUIRE, semitivade en 1553. Opanque Anguedidorico el infiemnito,

O ANTINE BOLING LA PRIMAVERA, et ille ve . pre det rie Core

OMONASTERIO DEL SANTO ECCE- HONO, Jundade en 1630 par les Podres Dominica.

y plantes de certenares de metros.

CUEVA DEL MAYAL, en une impresentation ante de de la quebruda Baltecias

CARDN DEL RID MONIQUIRA y anniero penned-

WINAS DE MARMOL, Enforce verde, porde y es

Senders passes being basis of DABIS Y EL DE BIERTO DE LA CANDELARIA

ADRASTERIO DE LA CANDELARIA, Perdudo a ED4 por los Podres Agostinas

ACTION DELLACO, la baserar ancientaria de la CERESIÓN DEL LOCO, la baserar de las decipas erronori a Tunyo y el puestos de Childuiza cuer rober present actigues.

Site Survey tools

Map, altimeter, laptop with RSL software

110

Binoculars or Telescope

CARTA GEOGRAFICA Y TURISTICA DE LA REGION DE

VILLA DE LEYV

BOYACA - COLORDIA

Pat Sarmin Paarta Restrant Aparmin 24379, Septia

Ether Deservition Annual Marin, Claury Section Anna Frank, Marine and Kar Lafe

Transfer Stat. (10), 10, 20 (10), Sar



Ing Street

Site Survey

The site survey is paramount for a successful install
Besides the previously listed tools, a digital camera will help in the documentation process and facilitate the work should another team undertake the install
Spotlights and mirrors may be used in long distance links

A balloon may also be useful to verify line of sight and the height of the required tower

Site Survey

Site survey means working in roofs and elevated structures Remember to wear a hat, sunglasses and sunscreen Gloves and harness are a must for climbing towers Plan ahead for the permits to access roofs and ladders, find out who has the keys

Requirements for the base station mounting structure

Location of the base station is by far the must important consideration, in order to have the best coverage. Access to the power grid, security of the equipment and accessibility of the site come next



2/16/2006


Requirements for the base station mounting structure

Sometimes an existing tower can be used for the new install, if an agreement with owner can be arranged The alternative is to build a supporting structure of your own

2/16/2006

Antenna Mount Options

Free standing Pole Side Mount **Roof Mount** Penetrating Non Penetrating **Climbable tower** Guyed Self Supporting



Free standing pole

Often it is less expensive than a tower, and can be built by attaching foot rests to any sizable pipe

Transceiver

Mast

Wall Mount (side view)

Cable —

Antenna

For applications where the roof is not flat or strong enough to hold the weight of the non-penetrating roof mount the wall mount is the most effective solution This mount is affixed to the side of a building, wall or chimney

Wall mount

The structure must be capable of handling the weight of the mast, antennas, and transceiver plus wind loading stress.

This type of mount requires drilling four holes into the structure.

When mounting to masonry, expansion type bolts or lead anchors should be inserted into the hole drilled as a means of attaching the mounting bracket to the structure.

Non Penetrating Rooftop Mount

At least 4 cement blocks (to be used as ballast) or equivalent, are also required. 1 piece of 90 cm x 90 cm rubber padding can be placed under the assembly to provide roof protection.

Mast____

Cable

Transceiver

Antenna

Tripod Antenna Møunt

Cement Blocks

Non penetrating mount example

This home made example can be fitted with containers filled with water or sand to increase wind resistance



Penetrating Roof Mount

Care must be taken in order to prevent water from seeping in through the attachment bolts



2/16/2006

Guyed Tower

A climbable tower is normally made of aluminum with a triangular cross section, about 30 cm per side. Each section is about 3 m long and several sections can be bolted together to attain the required height The tower must be properly guyed to withstand the expected wind in the area, as well as to support the weight of the equipment and one person



Security

Always use a harness securely attached to the tower when working at heights

Security



 Many countries require special training for people to be allowed to work on towers above a certain height
 Avoid working on towers during strong winds or storms

2/16/2006

Security

A lightning rod is a must for any structure elevated above the surrounds. An inexpensive solution is to use a grounding rod properly-connected to ground. Towers should also be fitted with warning lights and painted white and red for added visibility

Erecting a tower with a pulley



A pulley attached to the top of a pole will facilitate the tower installation
The two tower sections are attached with an articulated joint

Use tensors and proper fittings for the guy wires



2/16/2006

Self Supporting Towers

- Self supporting towers are expensive but sometimes needed for the Base Station
- An existing tower can sometimes be used for subscribers, although AM Transmitting station antennas should be avoided because the whole structure is active.
- FM station antennas are O.K.

The first choice for a base station is an omnidirectional antenna. An omni will provide maximum coverage for your money. Unfortunately, the best location for the omni antenna is at the top of the tower. Very often this location is already taken so one must resort to attach the omni to one side of the tower.

Area of coverage

Base Station with antenna set to 0 degrees take off angle

10 degrees wide beam width Area of coverage

Base Station with antenna set to -10 degrees take off angle

10 degrees wide beam width

Area of coverage

Area of coverage

Coverage area with antenna set to -10 degrees elevation angle

Coverage area with antenna set to 0 degrees elevation angle

Base Station


2/16/2006

Omni antennas have 3 basic specifications: •VSWR •Vertical radiation pattern •Horizontal radiation pattern. Any nearby metal object will affect all of these

This is easy to understand if one considers the functioning of a Yagi-Uda antenna:

We have only one active element, but the addition of the reflector and the directors will affect the gain. So any conducting object that is spaced from our antenna less

than 2 wavelengths will affect the performance



VSWR


A sizable conducting object will reflect part of the signal. Radio hams some times tune the VSWR of an antenna by changing its distance from the tower.

A number of coaxial cables or waveguides can constitute a big enough reflector. Separating the antenna at least 25 cm will be enough to overcome this effect at 2.4 GHz



Horizontal Radiation Pattern


The horizontal pattern of an omni approaches a circle. A small pipe near the antenna can act as a director or reflector, changing the gain up to 3 dB in certain directions, thus disrupting the radiation pattern. A sizable object like the back of a parabola can completely block the signal in a given direction



Vertical Radiation Pattern

The gain of an omni is obtained by narrowing the vertical pattern.

This applies when the antenna is far from conducting objects, and constitutes a good approximation when the antenna is at the very top of the tower



A self supporting tower very often has a tapered design, becoming narrower with height. This will uptilt the beam of a side attached omni up to 5 degrees. A typical 15 dBi omni has an 8 degree vertical beamwidth. The beam can be tilted upwards so much as to send all the signal where it does no good.



Sectorial Antennas are less affected by the tower and can easily be downtilted. This is particularly necessary when the subscriber is close to the base station or when the base station is much higher. Mechanical downtilting can compensate for the effect of the structure. Electrical downtilting can be accomplished by changing the phase of feeding elements.



Subscriber Antenna Mounting Considerations



 Locate the antennas so that they have clear line of sight to the antennas at the opposite endpoint of the link.
 There should be no obstructions within ±10 degrees azimuth of the antenna bore sight.

Subscriber Antenna Mounting Considerations

Mounting the antennas close to the edge of the rooftop (on a flat top roof) helps to avoid problems with the latter requirement and with reflections. This should be done at the edge facing the air

Subscriber Mounting Considerations

Other considerations include proximity to the cable run to the rooftop.

When locating the antenna mast it is desirable to have it in close proximity to the building rooftop ground system if present. It then becomes a simple matter to provide a short, low resistance, connection to the building ground system.

Subscriber Mounting Considerations

Conditions for microwave path design must be considered such as Earth curvature and Fresnel zone clearance. * Observe local building and electrical codes when running all cables.

Protect connectors from exposure

Connectors should be protected with special tape or compound, since humidity cropping in is the main observed cause of CPE failures Cables should have dripping loops to prevent water getting inside the transceiver An inexpensive way to protect connectors is by means of innertube rubber, this can be wrapped around the connector providing a non sticking, reusable protection* (patente pending)

Equipment

- Two or more radios
- Antennas (depend on install requirements)
- Antenna Mount (non penetrating, pole, wall mount, etc)
- COAX Cable 50 Ohm LMR400 or LMR 600
- Appropriate connectors
- Crimp and Soldering tools

Make sure you follow local code and ord's
MTBR for down links can vary, have spare parts
Do a free space loss calculation:
L = 100,4 + 20 log(km)

Do a "Test Install" first: take a 2 m pole and attach a 24 dBi dish connect to radio and search for other end

- verify connectivity quality and strength
- note general heading of antenna
- note elevation (did you have to lift it up, etc)
- now try antenna you plan to use

Most important part of install (Antenna)

- Make sure the mount is STRONG
- Will NOT move in wind (antenna loads are high)
- Well grounded, ground rod or similar
- Cable is tied down with gentle sweeps
- Lightning arresting equipment is grounded
- Use a rubber mat for skids, to protect roof

Keep COAX length SHORT No more than 15 meters Tape and secure ALL connections **Use All Weather Tape** NOT Electrical tape or duct tape Use BLACK Nylon Ties White ones will break down in UV If able, place COAX in conduit for protection

Summary

- Location of the base station antenna is paramount for good coverage
- If available, sharing an existing structure can be very convenient
- Non penetrating roof top mounts are preferred Guyed towers are cost effective and can be locally manufactured
- Grounding and lightning protection required for a successful operation