

# Antennas and Transmission lines

Ermanno Pietrosemoli



The Abdus Salam  
**International Centre  
for Theoretical Physics**

# Antenna and transmission line irrigation analogy

Irrigation requires:

A hose to transport the water to the  
sprinkler


**transmission line**

A sprinkler to direct the water to the  
specific area we want to irrigate

**antenna**



- ▶ An **antenna** is the structure associated with the region of transition from a guided wave to a free space wave, radiating RF energy.
- ▶ A **transmission line** is a metallic device used to guide radio frequency (RF) energy from one point to another (for example a **coaxial** cable or **bifilar** line).



# Transmission Line


A ***transmission line*** is the device used to guide radio frequency (RF) energy from one point to another (for example a coaxial cable, a bifilar line or a waveguide).

Every transmission line will attenuate the signal.



# Transmission Line

The simplest ***transmission line*** is the **bifilar** line formed by two parallel conductors separated by air or an insulator. It will carry the RF signal from the source to the other end. There can be an alternating current even in an open ended transmission line, since the electrons will flow back and forth every half cycle



# Transmission Line

The electric field at a **distant** point created by the each of the currents will be of the same magnitude but in opposite direction and will therefore cancel.



## RF signal source






# Bent ends transmission line

If we bend one extreme upward and the other downward, the currents will now flow upward in both segments and therefore the electric fields created will reinforce. The resulting electric field will cause a current to flow in any conductor present there.

$E \uparrow \uparrow E$

We now have an antenna!




# Irrigation system components






# Wireless system components



# Coaxial transmission lines



# Coaxial transmission lines

The loss (or **attenuation**) of a coaxial cable depends on the construction of the cable and the operating frequency. The total amount of loss is proportional to the length of the cable.

Cable Type	Diameter	Attenuation @ 2.4 GHz	Attenuation @ 5.3 GHz
RG-58	4.95 mm	0.846 dB/m	1.472 dB/m
RG-213	10.29 mm	0.475 dB/m	0.829 dB/m
LMR-400	10.29 mm	0.217 dB/m	0.341 dB/m
LDF4-50A	16 mm	0.118 dB/m	0.187 dB/m

<http://www.ocarc.ca/coax.htm>

# Impedance


All materials will oppose the flow of an alternating current to some extent. This opposition is called **impedance**, and is analogous to resistance in DC circuits.

Most commercial communication antennas have an impedance of 50 ohms, while TV antennas and cables are usually 75 ohms.

Make sure that the characteristic impedance of the cable between the radio and the antenna is 50 ohms. Any mismatch will cause undesired reflections and power loss.

# Reflections and VSWR



Impedance mismatch causes reflections and increased VSWR.



$$\text{Voltage Standing Wave Ratio VSWR} = \frac{V_{\max}}{V_{\min}}$$

# Matched impedance = maximum power transfer

Any mismatch will cause a loss, which can be very high



# Connectors

Connectors come in a huge variety of shapes and sizes. In addition to standard types, connectors may be **reverse polarity** (genders swapped) or **reverse threaded**.



MC-Card



MMCX



RP-MMCX



U.FL



SMA Male



RPSMA Male



SMA Female



RPSMA Female



TNC Male



RPTNC Male



TNC Female



RPTNC Female



N-Male



N-Female



# Adapters & Pigtails

Adapters and pigtails are used to interconnect different kinds of cable or devices.



SMA female to N male



N male to N male



N female to N female



SMA male to TNC male



U.FL to RP-TNC  
male pigtail



U.FL to N male pigtail



SMA male to N female

# Theory: isotropic antennas

An **isotropic antenna** radiates the energy fed into it equally in every direction in space. It is only an ideal model and cannot be built.

Real-world antennas are characterized by their ability to radiate more strongly in some directions than in others; this is called **directivity**.

When taking the efficiency of the antenna into account, this preference for a direction of radiation is referred to as **gain**.

$$G = \text{Efficiency} * \text{Directivity}$$

# dBi

Antennas do not add power. They direct available power in a particular direction.

The gain of an antenna is measured in **dBi** (decibels relative to an isotropic radiator).



# Omnidirectional antenna

An omnidirectional antenna spreads the signal evenly in every direction of the plane



# Directional Antenna

A directional antenna forms a very narrow beam in a specific direction and very little energy is directed elsewhere.

If the beam becomes much wider we will have a sectorial antenna






# Sectorial Antenna

Spreads the signal in certain angle of the plane, for instance 45 degrees, 60 degrees, etc.

Often combined in a base station to provide 360 degree coverage, for instances 3 sectors of 120 degrees each.



# Directional vs. Omnidirectional





# Antenna features





When buying an antenna, what features are important to consider?

- ▶ Usable frequency range (bandwidth)
- ▶ Radiation pattern (beamwidth, sidelobes, backlobe, front-to-back ratio, location of nulls)
- ▶ Maximum gain
- ▶ Input impedance
- ▶ Physical size and wind resistance
- ▶ Cost

# Radiation pattern



The ***radiation pattern*** of an antenna is a pictorial representation of the distribution of the power radiated from, or received by, the antenna. This is presented as a function of direction angles centered on the antenna.

Radiation patterns usually use a polar projection.




# Beamwidth

The **beamwidth** of an antenna is the angular measure of that part of the space where the radiated power is greater than or equal to the half of its maximum value.



# Polarization

- ▶ The polarization of transmitting and receiving antennas **MUST MATCH** for optimum communications.





# Antenna polarization



# Reciprocity

Antenna characteristics like gain, beamwidth, efficiency, polarization, and impedance are independent of the antenna's use for either transmitting or receiving.

Another way to state this is that an antenna's transmitting and receiving characteristics are ***reciprocal***.



# Wind load

Parabolic  
Antenna  
with  
Radome



Sector  
Antenna

Parabolic  
Grid  
Antenna



# Weather effects



parabolic grid



parabolic grid  
(covered by snow)


# Weatherproofing antennas




Most antenna problems are caused by coaxial cable connections that loosen due to vibration, allowing moisture to penetrate the connector interface.

Weatherproof all outdoor connections.

# Antenna types




# Half Wavelength Dipole



- ▶ Two  $1/4 \lambda$  elements
- ▶ Very easy to build over a wide frequency range
- ▶ Omnidirectional in the plane perpendicular to the elements
- ▶ 2.15 dBi gain
- ▶ 72 ohm input impedance nearly matches the 50 ohm coax

# Monopole or Marconi antenna

- ▶ Vertical element  $1/4 \lambda$
- ▶ A good ground plane is required
- ▶ omnidirectional in the horizontal plane
- ▶ impedance can be tuned by changing angle
- ▶ 5.15 dBi



Collinear (omnidirectional)


And

Yagi (directive) antennas





# Example of sectorial antenna usage





# Conclusions

- ▶ Antennas are the interface between guided and unguided waves.
- ▶ Antenna come in all shapes and sizes.
- ▶ The size of the antenna must be at least a fraction of the wavelength it handles.
- ▶ Antenna impedance must match the transmission line.
- ▶ There is no “best antenna” for every application; the choice is always a trade-off between reaching long distances and covering a wide area.
- ▶ Use high gain antennas to reach long distances, and omni or sectorial antennas to cover wide areas.

# Thank you for your attention

For more details about the topics presented in this lecture, please see the book ***Wireless Networking in the Developing World***, available as free download in many languages at:

*<http://wndw.net>*

